

AC ULTRA Plus Air-Conditioner Remote Control User's Guide

Product Description

The AC ULTRA Plus integrates over 1,000 codes with more than 10,000 models in one remote controller. With this huge range and quick programming make it the Number 1 Choice in Australia. It's easy; quickly scan to the correct or search manually. Once selected, the code is stored until changed. Features include: Timer ON and Timer OFF with accurate 24 hour clock display. *Please read this user's guide carefully before using, don't forget, when all else fails read the manual!*

Model setting of Remote Control

1. Open the battery cover, place the 2 X AAA (UM-4 or R03) batteries as per diagram indicated in the battery compartment.
2. Find the model from Brand Code List. If there is more than one code for one brand, you will have to try them one by one. e.g. for FUJITSU, try model codes 127 to 137 then 464 etc. For PANASONIC air conditioners try 138 first, if not, try 139 and so on. Next, lift the front cover.
3. To Program: Press the "SELECT" key, the codes on LCD will begin flashing. Press "TIME/CODE" + or - until required brand code appears. Then press the "ENTER" key, the brand code stops flashing. Aim at air-conditioner and press the "POWER" key, your remote is programmed and you can control your air conditioner. If not, select the next code from the table and test again.

Remote Control Search

If you don't know the brand of your air-conditioner or you cannot find the brand from brand code list, please operate as per the following steps:

1. Press the "SELECT" key, the code on LCD will begin flashing, point the remote control at the air conditioner, press "SELECT" key again and again. Each time a brand code is added and automatically emits a signal. Press and release until the air conditioner receives the correct signal and/or produces buzzer sound. Your air conditioner will either turn on or buzz. Then press the "Enter" key.
2. After turning on the air conditioner, try other function keys. If they do not work, repeat above steps finding the correct code. Write the number on the inside cover if for any reason you need to refer back to it.

Clock setting of remote control

1. Press the "CLOCK" key, the clock on LCD will flash.
2. Press "TIME/CODE" + or -, adjust to correct time. Time is in 24 hour format.
3. Press the "CLOCK" key again, your clock is now set.

Timer ON/OFF settings of remote control. (Remote must be in-line-of-sight!)

Timer ON: (can only be set with the air conditioner OFF)

1. Press the "TIMER ON" key, the clock signal on LCD appears and time flashes.
2. Press "TIME/CODE" + or - key, to adjust the time when you want the air conditioner to turn on automatically.
3. Timer flashes and it will stop after 5 seconds. The LCD display current time and

AC ULTRA Plus Air-Conditioner Remote Control User's Guide

clock signal. Setting is complete. To check the ON time (once set) simply press the "TIMER ON" once.

Timer OFF: (can only be set with the air conditioner ON)

1. Press the "TIMER OFF" key, the clock signal on LCD appears and time flashes.
2. Press "TIME/CODE" + or - adjust the time when you want to make the air conditioner turn off automatically.
3. Time flashes, and stops after 5 seconds. The LCD display current time and clock signal. Setting is complete. To check the OFF time (once set) simply press the "TIMER OFF" once. To nullify timer set to 0:00.

Note:

1. After timer setting is finished, make sure the AC unit and remote are in Line of Sight. The remote need to communicate with the AC unit to work.
2. If you want to see the timer settings, press TMR ON/OFF key, the LCD will display the time, and it will default to the current time after 5 seconds.
3. NOTE: You can only set the AC unit to go ON or OFF, not both at the same time.

Attention:

1. Batteries usually last between one and two years. If it is not used for a long time, remove the batteries to avoid battery leakage that could damage the machine. When the LCD looks dim, change both batteries. (New and old batteries can not be used together) After the batteries are replaced, it is not necessary to set model code again. You will need to set the time again.
2. If abnormal situation appears because of using wrong code reset the unit by placing pen tip or other item into "reset" hole. Press to restore normal status.
3. The LCD will display the code number when pressing the model code "Enter" key. After 5 seconds it displays the time.
4. Note: this remote control only works by direct Line of Sight. Check carefully there are no barriers between remote and air conditioner when using the timer ON/OFF function. Because the operation is effective only when the air conditioner receives the timer on/off signal from remote controller both units must be in Line of Sight of each other.
5. The manufacturer has the right to change the parameters and functions of this product.

Controllable distance: Up to 8 meters
Dimension: L127×W48×D22mm

Battery model: Battery AAA(UM-4,R03)×2
Weight: Approx 84g (with batteries)



Automatic



Cooling



Dehumidifier



Fan Only



Heat

Brand AC Ultra Plus Code		Brand AC Ultra Plus Code	
AIRWELL	0529, 0555, 0556	KELON	0282-0287, 0794, 0798, 0802
ACSON	0234	Kelvinator	0151, 0197, 0203
AGER	0489, 0785	KLIMATAIR	0225, 0226, 0452, 0738, 0964, 0966
ALPIN	0252, 0253, 0617, 0764, 0765	KOLIN	0416-0418, 0929, 0968
Arena	0206, 0212, 0229, 0718, 0724, 0741	KONKA	0397, 0457-0459, 0808, 0909, 0970
Arlec	0202	LENNOX	0260-0265, 0773, 0777, 0813
AUCMA	0288-0296, 0462, 0802, 0807, 0901	LG	0197-0200, 0504, 0567, 0572, 0710, 1016
Aussie Air	0809	LIANGYU	0233, 0451, 0745, 0837, 0963
AUX	0297-0300, 0451, 0810, 0960, 0963	LITTLE DUCK	0015-0020, 0528, 0531, 0639
BANSHEN	0264, 0678, 0776	LOREN-SEBO	0255, 0471, 0472, 0767, 0984
BOERKA	0383, 0434, 0436-0437, 0522, 0948	Luxaire	297
CARRIER WEATHERMAKER	0203-0209, 0482-0486, 0456-0458, 0563, 0565, 0721, 0967	MACQUAY	0234-0237, 0465, 0747, 0903
CELESTIAL	0307	MIDEA	0260-0265, 0773, 0777, 0813
CHANGHONG	0301-0308, 0627, 0815, 0820	MITSUBISHI (ALL)	0010-0045, 0476-0479, 0515, 0556, 0568, 0582, 0695, 0989
CHIGO	0379-0382, 0890, 0892, 0894	Mistral	0237
CHOFU	0184-0187, 0581, 0696, 0698	NEC NATIONAL	0138-0154, 0200, 0658, 0663, 0666
CHUNLAN	0345-0350, 0450, 0453, 0862, 0967	NORITZ	0431, 0859, 0943
CLIMA VENETA	0572	OMEGA	0559
CORONA	0155-0163, 0459, 0561, 0667, 0675	OMNI	0146, 0262
CONIA	570 571, 861	PANASONIC	0138-0154, 0483, 0491, 0658, 0663, 0666, 0483
CONROWA	0377, 0889, 1010	PANDA	0378, 0505, 0509, 0763, 0890
CONSUL	0463, 0734, 0975	PHILCO	0210, 0211, 0487-0490, 0723, 0999, 1000
Cooline	0187, 0206	PROTON	0421-0423, 0934, 0956
COUNTRY AIR	560	RAYBO	0362-0367, 0875, 0893, 1023, 1028
DAEWOO	0203-0209, 0406, 0718, 0818, 0918	POLAR ICE	0571
DAIKIN	0171-0183, 0566, 0567, 0685, 0693, 0696	ROWA	0369, 0438, 0439, 0732, 0881, 0950
DeLonghi	0232, 0482	SABRO	0435, 0506-0508, 0947, 1018, 1020
DOCTOR	0221, 0449, 0733, 0817, 0961	SAIJO DENKI	0212-0215, 0721, 0725, 0726
DONGBAO	0355-0361, 0869, 0873, 0875	SAMPO	0424-0426, 0931, 0936, 0938
DONGXINBAO	0413, 0891, 0925	SAMSUNG	0188-0196, 0503, 0701, 0707, 1015
ELECTRA	557	SANYO	0046-0095, 0562, 0598, 0605, 1011, 1016
ELECTROLUX	0216-0220, 0569, 0728, 0730, 0733	SASUKI	0254, 0470, 0654, 0766, 0982
EMAILAIR	0553, 0556, 0558	SHANGLING	0384-0388, 0444, 0445, 0896, 0900, 0956, 0989
FRESTECH	0277, 0665, 0789	SHANXING	0392, 0449, 0904, 0961, 0986
FUJITA	0297	SHARP	0096-0106, 0608, 0617, 0631
FUJITSU	127-137, 464, 509, 640, 648, 552, 554	SHENGFENG	0376, 0406, 0480, 0888, 0992
FUNAI	0430, 0481, 0802, 0942, 0993	SHINCO	0351-0354, 0454-0456, 0863, 0866, 0967, 0996
GUQIAO	0244, 0491, 0756, 0803, 1003	SHUANGLU	0376, 0404-0407, 0480, 0916, 0919
GALANZ	0371, 0372, 0883, 0992	SHUAI KANG	0288, 0587, 0800
GLEE	0398, 0399, 0521, 0910	SONGGE	0428, 0429, 0940, 0949
GOLDSTAR	0201, 0466-0469, 0713, 0978, 0980	SOVA	0409, 0410, 0632, 0922
GREE	0309-0316, 0822, 0827, 0830	SUMMER	0427, 0672, 0939
HAIER	0266-0272, 0453-0455, 0781, 0964	SUNDURG	0257, 0505, 0769, 0815, 1017
HOFFWEL	0107, 0282, 0289, 0811	Starway	0714, 0345, 0859
HISENSE	0332-0335, 0340, 0671, 0681, 0845, 0847	SWAN	0434, 0732, 0946
HITACHI	0118-0126, 0500, 0501, 0631, 0637	TADIRAN	0246-0251, 0758, 0762, 0925
HOFFWELL	0811	TATUNG	0419, 0420, 0876, 0931
Homemakers	0297-0300, 0451, 0810, 0960, 0963	TCL	0273-0281, 0570, 0786, 0790, 0792, 0861
HUABAO	0336-0344, 0848, 0852, 0855, 0858	TECO	0008, 0256, 0473-0475, 0482, 0619, 0768, 0986
HUAKE	0408, 0493-0498, 0920	TIANDI, MICOM	0415, 0643, 0927
HUAMEI	0402, 0460-0465, 0816, 0914, 0976	TOSHIBA	0107-0117, 0493-0499, 0561-0562, 0620, 0629, 0815, 1011
HUALING	0317-0325, 0452, 0830, 0835, 0965	TRANE	0227-0232, 0598, 0739, 0743

HUIFENG	0370, 0510, 0512, 0882, 1023	UNI-AIR	0222-0224, 0450, 0735, 0871, 0962
HUIKANG	0368, 0441-0443, 0880, 0938, 0954	WEILI	0393-0396, 0905, 0908, 0986
HYUNDAI	0202, 0433, 0550, 0551, 0609, 0714, 0945	WHIRLPOOL	0164-0170, 0502, 0678, 0729, 1014
JDC	0373, 0440, 0885, 0952, 0956	WINIA	0550
JIANGNAN	0432, 0944, 1004	XILENG	0411-0412, 0526, 0923
JINDA	0414, 0499, 0504, 0926, 1012	XINLE	0400, 0401, 0623, 0912
JINSONG	0389-0391, 0468-0448, 0902, 0959, 0989	YANGZI	0403, 0489-0492, 0915, 1004
JOHSON	0245, 0492, 0757, 0989, 1004	YINYAN	0258-0259, 0326-0331, 0770, 0838, 0843, 0941
KANGLI	0374, 0375, 0654, 0886	YORK	0238-0243, 0573, 0750, 0753, 0755